

## Instructions for COAST HP3 Focusing Pen Light

**BATTERY INSTALLATION:** Turn the end cap where the power switch is located in a counter-clockwise direction to remove the cap. Place two AAA batteries into the light, positive end of the battery first. Replace the tail cap and turn it clockwise to tighten it until it is fully closed. Never mix old and new batteries. Remove batteries before storing flashlight during non-usage.

**QUICK CYCLE SWITCH ACTIVATION:** This flashlight is equipped with COAST's Quick Cycle Switch™, featuring high and low beams. To activate the high beam from the off position, press the on/off switch until it clicks once, then release. Press the on/off switch until it clicks a second time to turn off the light. To activate the low mode, press the on/off switch until it clicks a third time, then release. The light can also be operated in "momentary" mode. Momentary mode is activated by partially depressing the on/off switch (less pressure than required for a full click). The momentary switch will cycle the light through the high and low beam modes. Any time the light is turned off for more than five seconds, the high/ low cycle will reset and the high beam will be activated when the light is turned on again.

**UNIVERSAL FOCUSING OPTIC with TWIST FOCUS:** This flashlight is equipped with COAST's Universal Focusing Optic with Twist Focus that allows the user to choose between a broad flood beam and a focused spot beam for long distance illumination. To adjust the beam into the spot mode, turn the front bezel of the light clockwise. To adjust the beam into the broad, flood light mode, turn the front bezel of the light counter-clockwise.

**MAINTENANCE:** Wipe the external body with a damp cloth. Do not submerge.

**WARRANTY POLICY:** Coast Products guarantees this product to be free of defects in materials and workmanship for the life of the original purchaser. This guarantee does not cover normal wear and tear, nor damage resulting from misuse or neglect. If this product is defective, return it to us for a repair or replacement, along with a check for \$5.00 shipping and handling. Guarantee does not include batteries.

In USA:

COAST Warranty  
8033 NE Holman Street  
Portland, OR USA 97218  
800.426.5858