

Style C5899 2 LED Pro Pocket Pliers

Battery installation

Battery compartment is located at the side of the handle (Fig.1)

To open the battery compartment:

Push the release button forward by finger nail or small flathead screwdriver (Fig. 2 & 3)



Fig. 1



Fig. 2



Fig. 3

Pull the battery compartment out from the handle (Fig.4)



Fig. 4



Polarity of batteries inside
the battery compartment

Replace the batteries in correct polarity and close the battery compartment

Battery: 2 x CR1616 (included)