HP21 Instructions:

Battery Installation

- Turn the end cap in a counter-clockwise direction to remove the cap.
- Place four D batteries into the light, the positive (+) pole on each battery should be inserted first.
- Replace the tail cap and turn it clockwise to tighten it until it is fully closed.

Quick Cycle Switch Operation

This flashlight is equipped with COAST's Quick Cycle Switch™, featuring high, strobe and low beams.

- To activate the high beam, press the on/off switch until it clicks once, then release.
- To activate the strobe mode, press the on/off switch until it clicks a second time, then release.
- To activate the low mode, press the on/off switch until it clicks a third time, then release.
- At any time you can activate the high beam in "momentary" mode by partially depressing the on/off switch.
- Any time the light is turned off for more than five seconds, the high/strobe/low cycle will reset and the high beam will be activated when the light is turned on again.

Pure Beam Focusing Optic with Speed Focus

- This flashlight is equipped with COAST's Pure Beam™ Focusing Optic that allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot™ beam for long distance illumination.
- To adjust this, hold the flashlight body with one hand and then with the other hand pull the rubber bezel ring forward to produce the Bulls-Eye Spot™ beam or push it back to produce the broad flood beam.

Accessories:

Shoulder Strap

- The HP21 includes a shoulder strap for carrying the light. To use the strap, slide the support rings onto the body of the light, from the rear.
- One ring should be positioned near the head of the flashlight. The second should be positioned near the tail of the light.
- Attach the strap to the support rings with the included clips.

Belt Ring

- The included belt ring can be used to hang the HP21R from a belt.
- Thread your belt (not included) through the nylon strap on the belt ring. Position the light in the desired location on your waist usually the left or right hip area.
- Insert the tail of the light through ring.