

PX20 Instructions:

Battery Installation

- Turn the head of the light in a counter-clockwise direction to remove from body of the light.
- Remove the battery cartridge.
- Place three AAA batteries into the cartridge in the direction indicated on the cartridge.
- Replace the cartridge in the light with the red end going in first.
- Replace the tail cap and turn it clockwise to tighten it until it is fully closed.

On/Off Operation

- ThePX20 has separate switches for each of the two colors.
- To activate the white light, press the gray or black switch, depending on the body color of the light. This switch is textured to allow identification in the dark.
- To activate the red light, press the red switch.